

**8KVA ~ 10KVA
Double conversion
On-Line UPS
(Low Frequency)
Tower Type**

User Manual

*** CONTENTS ***

1. INTRODUCTION	1
2. FUNCTION	2
3. LOCATION OF THE UPS	5
4. CABLE CONNECTION	8
5. OPERATION	15
6. TROUBLE SHOOTING GUIDE.....	18
7. OPERATION MODES OF THE UPS	28
8. COMPUTER INTERFACE	32

1. INTRODUCTION

1.1 General Description

The continuity of electrical power is an essential requirement for critical load operations. The Uninterruptible Power System is designed to meet the user's need of present mini-computer, micro-computer and the equipment of office automation that make the UPS more compact and less noisy.

To choose the UPS as your equipment protector is a wise investment because it supplies reliable, pure and stable power at affordable price.

1.2 Five key features

- 1.Compact size.
- 2.Light weight, easy to transport and place.
- 3.Special airflow design to avoid dust accumulation.
- 4.Front door installation and repairing. Considerate and user friendly design.
- 5.Green Power minimizes environment pollution.

1.3 Important Notices

To be sure that the UPS will be operated correctly, the following items should be noticed:

- 1.Read instructions carefully before operating the UPS.
- 2.All operating instruction should be followed.
- 3.Be careful not to damage the UPS while transporting.
- 4.UPS power connect instruction should be followed.
- 5.Please don't open the case to prevent danger.
- 6.If the UPS will be stored for long period, the battery must be charged once every 90 days.
- 7.Retain the load within the rating of UPS to prevent faults.
- 8.Keep the manual for reference.
- 9.Handle unusual events according to the trouble-shooting guide.
- 10.Keep the UPS clean and dry.

2. FUNCTION

- 1.Input LED : This indicates the incoming AC line is normal.
- 2.Bypass LED : This indicates the output outlet is supplied via bypass.
- 3.Output LED : This means the UPS power is from its inverter to the load.
- 4.Battery Capacity LED : The batteries are almost exhausted out.
- 5.Overload LED : This indicates the UPS is connected with overload.
- 6.Fault LED : This indicates an UPS fault condition.
- 7.LCD Display: This indicates digital signals.

(1) UPS STATUS

AC: LOSS (OK) BAT: OK(LOW)

NO OUTPUT (BYPASS OUTPUT, INVERTER OUTPUT)

(2) INPUT VOLTAGE

(5) OUTPUT FREQUENCY

(3) OUTPUT VOLTAGE

(6) BATTERY VOLTAGE

(4) INPUT FREQUENCY

(7) OUTPUT POWER




Figure 1 : Front View LCD Indicators

8.LCD Switch : This switch is pressed to select the UPS status on LCD Display.

9.PUSH ON-OFF Switch (SW4): To turn the UPS on or off.

10.INPUT BREAKER (SW1): To control the AC input power.

11.BYPASS BREAKER (SW2): To supply AC input power into Bypass output.

12.BATTERY BANK BREAKER (SW3): To control external batteries.




Figure 2 : Front View of Outer Construction




Figure 3: Rear View of Outer Construction

13.DB-9 Interface: Communication port between the UPS and computer.

14.Ventilation Holes: Please keep the ventilation holes free.

15.Power Cords Holes: Input/output power cords and batteries power cords channel.

3. LOCATION OF THE UPS

3.1 Transporting

1. Disconnect all power cables if necessary.
2. Be careful not to damage the UPS while transporting.
3. Don't move the UPS upside down.

3.2 Positioning

1. Do not put the UPS on rugged or declined surface. (Fig.4)
2. Allow a minimum distance of 10 cm in the rear and two sides of the UPS for ventilation. (Fig.5)
3. Do not expose the UPS to direct sunlight or rain. (Fig. 6,7)




Figure 4 : UPS Positioning




Figure 5




Figure 6



Figure 7

4.Keep the UPS far away from heat emitting sources. (Fig.8)

5.Do not leave objects on the top of the UPS. (Fig.9)

6.Do not expose it to corrosive gas. (Fig.10)

7.Ambient temperature : 0°C - 40°C




Figure 8





Figure 9




Figure 10

4. CABLE CONNECTION

4.1 Caution

1. Do not use household outlet (only 15A), because the outlet hasn't sufficient capacity to support the UPS.
2. Please connect the 220V power of nearest switch box to UPS input terminal block. (Fig.11)




Figure 11

4.2 Power Supply Connection

1. First, detach 4pcs screws on the rear panel with a screwdriver to find the terminal block. (Fig.12,13)




Figure 12

- 2.Once power cords are connected, make sure all connectors are made properly and all the terminal block screws are tightened.
- 3.The hole to insert input/output power cords is on below of the rear panel.
Please connect power cords from the hole.
- 4.Use power cables to connect the LINE(L), NEUTRAL(N) and GROUND(G) lines to the connector terminals.




Figure 13

5.The checklist of input current and input power cord is as below.

MODEL	INPUT CURRENT	INPUT POWER CORD
10KVA	60A	22 mm ² (SOFT CORD)
8KVA	51A	22 mm ² (SOFT CORD)

6.Once the input power cords are fixed, please check to confirm that the conductors are unable to contact with the case or other conductive material to avoid short circuit.

7. Please turn off AC supply to prevent short circuit while connecting lines.

8. Please follow an electrician law.




FIGURE 14

NOTE: THE UPS IS 220V/240V SYSTEM, PLEASE DO NOT CONNECT WITH 110V AND 380V. IF YOU NEED TO MOVE THE UPS OR RESET WIRE, PLEASE FOLLOW ABOVE INSTRUCTIONS.

4.3 Output Connections

1. Please refer to Fig.15 for connections.
2. Please follow load current design for output power cord.
3. Ensure the connected load doesn't exceed the capacity of the UPS.




Figure 15

4.The checklist of output current and output power cord is as below.

MODEL	OUTPUT CURRENT	OUTPUT POWER CORD	TERMINAL
10KVA	46A	14 mm ²	14-6
8KVA	37A	8 mm ²	8-6

5.Improper use of the grounding plug can result in a risk of electric shock.

Consult a qualified electrician or serviceman if the grounding instructions are not completely understood.

6.Please provide good grounding system.

7.Please use the nearest point of earth bar or switch box for GROUND line.

(Fig.16)




Figure 16

5. OPERATION


5.1 Check Prior to Start Up

- 1.Make sure the “Main Breaker” and “PUSH ON-OFF switch” are in the OFF.
- 2.Ensure the UPS is in a suitable location. (Refer to Fig.4-10)
- 3.Check input cord is secured.
- 4.Make sure the load is disconnected or in the “OFF” position.
- 5.Check if input voltage meets the UPS requirement ($220V \pm 10\%$).


5.2 Initial Start Up Procedure

Please follow the instructions below to start the UPS. (Refer to Fig.1,2,3)


- 1.Be sure “Main Breaker” (SW1, SW2, SW3) and “PUSH ON-OFF switch” (SW4) in the condition “OFF” and no load to be connected to output terminal of UPS.
- 2.Pull “Main Breaker” up to “ON” position; LED of “Input” and “Bypass”, should light up simultaneously.




3.Press “PUSH ON-OFF switch” to the position ” ON “ , “LCD Display” shall light up immediately to indicate the AC utility power and batteries are normal. And the output outlet is supplied via bypass.



4.About 20 seconds later, “Output LED” will also illuminate and “Bypass LED” fade out at the same time, indicating UPS is operating correctly. The UPS power is from its inverter to the load.



5. Disconnect AC input of UPS for blackout simulation, the “Input LED” will extinguish and UPS beeps every 4 seconds to remind user AC failure. This means UPS is in the condition of battery operation. The beep will stop automatically after 90 seconds. When approaching battery low level, UPS will beep every second for warning purposes.



6. Re-supply AC utility power, “Input LED” will light up again, then first installation is completed. You can connect your equipping load into output terminal of UPS.

5.3 Normal Operation

Daily operation procedure :

Press “PUSH ON-OFF Switch (SW4)” to turn on or off the UPS.

5.4 Storage Instruction

1. Turn off the UPS and “Main Breaker” if you will not use it for long period.
2. If you do not use the UPS over 3 months, please follow initial start up procedure and keep supplying power to the UPS for at least 24 hours to ensure battery fully recharged.

6. TROUBLE SHOOTING GUIDE


6.1 Symbol Reference

	LIGHTS UP		EXTINGUISH		FALSH
					
BUZZER SOUNDS CONTINUOUSLY	BUZZER SOUNDS EVERY 4 SECONDS	BUZZER SOUNDS EVERY SECOND	BUZZER NO SOUND		

6.2 UPS Status and Action

The description of the following guideline may be helpful in problem solving.

1. LED STATUS as below:




UPS STAUS:

AC utility power is normal, UPS is running normally with full load.

ACTION: No.

2.LED STATUS as below:




UPS STATUS:

AC utility power is normal, UPS is running normally. Batteries have been charged to 90% or more.

ACTION: No.

3.LED STATUS as below:




UPS STATUS:

AC utility power is 220V, UPS is running normally.

ACTION: No.

4.LED STATUS as below:




UPS STATUS:

AC utility power is normal. UPS is running normally, but battery capacity is low.

ACTION: Charger broke down. Please replace charger board.

5.LED STATUS as below:




UPS STATUS:

AC utility power is normal. The output load is supplied by utility power. If "PUSH ON-OFF Switch" is not on, UPS does not start up.

ACTION: Refer to flowchart Fig.18.

6.LED STATUS as below:




Bz

UPS STATUS:

AC utility power is normal but UPS is overloaded. “Overload LED” lights up and buzzer beeps continuously.

ACTION: Please reduce the critical load to $\text{POWER}(\%) < 100\%$. If the situation continues, Please refer to flowchart Fig.19.

7.LED STATUS as below:




Bz

UPS STATUS:

AC utility power is normal, but UPS is abnormal. The load is supplied by AC utility power via bypass.

ACTION: Refer to flowchart Fig.20.

8.LED STATUS as below:




UPS STATUS:

AC utility power fails .The load is supplied by battery power in UPS .The UPS is connected with full load. Buzzer alarm sounds every 4 seconds.

ACTION: If AC utility power fails, reduce the less critical load in order to extend backup time. If it is not abnormal power failure, refer to flowchart

Fig.17

9.LED STATUS as below:




UPS STATUS:

AC utility power fails .The load is supplied by UPS, and battery power is running out. Buzzer alarm beeps every second.

ACTION: UPS will shut down automatically. Please save data soon.

10.LED STATUS as below:



UPS STATUS:

AC utility power fails and battery runs out. UPS has shut down automatically.

ACTION: UPS will restart up when AC utility power is restored. If AC utility power failure is more than 6 hours, please follow storage instruction.




Figure 17: Trouble Shooting Guide




Figure 18: Trouble Shooting Guide




Figure 19: Trouble Shooting Guide




Figure 20: Trouble Shooting Guide

7. OPERATION MODES OF THE UPS

7.1 UPS System Block Diagram (Fig.21)




Figure 21: UPS System Block Diagram

7.2 Normal Operation (Fig.22)

There are two main loops when AC utility is normal: the AC loop and the battery charging loop. The AC output power comes from AC utility input and passes through AC/DC rectifier, DC/DC booster, DC/AC inverter and static switch to support power to load. The battery charging voltage comes from AC utility input and converted by AC/DC charger to support battery-charging power.




Figure 22: Show How UPS Works when AC Utility Supplies

7.3 AC Utility Failure (Fig.23)

The AC output comes from battery, passing through DC/DC converter, DC/AC inverter and static switch within the battery backup time.




Figure 23: Show How UPS Works when AC Utility Fails.

7.4 Bypass Enable (Fig.24)

Under the following 5 conditions, the bypass will be enabled:

1. Overload.
2. Inverter failure.
3. Inverter start initially (about 20 seconds).
4. Turn off, SW4 is pressed.
5. Over-temperature




Figure 24: Show How UPS Works in Bypass Mode

7.5. Battery and Recharge

1. UPS is "ON", or Input breaker SW1, Battery breaker SW3, Bypass breaker SW2 are ON, batteries can be recharged automatically, and about 8-10 hours to 90% capacity.

2. Battery Back Up Time (Fig.25)




Figure 25: Battery Back Up Time

3. Please contact the agent, if the external battery set is needed to extend the backup time.

(1) Please keep battery fully recharged to extend the battery life.

(2) There are no customer serviceable components inside, do not open the cover or attempt to serve the unit. High voltage may remain when the unit shuts down.

(3) Please follow all operational instructions.

7.6 Daily Maintenance

- 1.The environment in which the UPS is located must be kept dry and relatively dust free.
- 2.The exterior panels can be cleaned with a mild cleaning solution.
- 3.All power connections at the input, battery, output terminals and circuit breaker must be periodically checked every month.
- 4.The battery cells used are the sealed maintenance-free type. The factory adjusts both charging voltage and current according to the battery specifications.
- 5 If external battery is the vented lead-acid type, the electrolyte should be inspected every three months. If liquid level is below the low limit, pure water must be added to the battery cells.

8. COMPUTER INTERFACE

The communication interface (DB9 port) on the back of the UPS may be connected to a host computer. The port provides two different modes for communicating with the computer.

Mode 1: Supply **RUPS** monitoring and management software.

Mode 2: Supply **RUPSII** monitoring and management software (default).

8.1 DB9 PIN Assignment

1.Change to Mode 1 or Mode 2 of Method

Mode 1: Supply RUPS Monitoring And Management software

The port simulates relays closing to communicate with the computer. Its major functions are as follows.

- (1) To broadcast a warning when power fails.
- (2) To close any open files before the battery exhausted out.
- (3) To turn off the UPS.


Mode 2: Supply RUPSII Monitoring And Management software

The UPS communicates with the computer by sending out RS-232 data streams to one of the serial ports. By this method the user is able to monitor the following parameters.

Input Voltage	Indicates the present input voltage to the UPS system when AC power is present.
Output Voltage	Indicates the present output voltage of the UPS.
AC Frequency	Indicates the actual output frequency of the UPS.
Battery Voltage	Indicates the present DC voltage of the UPS battery.
Temperature	Indicates the actual temperature inside the UPS.

8.2 DB9 PIN Assignment

- PIN 1: UPS Fault
- PIN 2: AC POWER Failure
- PIN 3: Inverter Power On
- PIN 4: Common GND of Pin 1,2,3,5,8
- PIN 5: UPS Battery Low
- PIN 6: Turn off UPS
- PIN 7: GND of PIN6
- PIN 8: inverter Output
- PIN 9: RS232 TXD



DB9 INTERFACE CONNECTOR

8.3 Change to Mode 1 or Mode 2 of Method

Change JP1 Short-Jump according to your requirement.

